

## Tabela zamienników baterii do zegarków

Renata No:	Energizer Everyready	Maxell National Panasonic Sony Toshiba	Varta	Rayovac	Duracell	Philips	Bulova	Timex	Citizen	Seiko	I.E.C.	J.I.S
301	301	SR43SW	V301	301			226	D	280-01	SB-A8	SR1142SW (SR43)	
303	303	SR44SW	V303	303				A	280-08	SB-A9	SR1154SW (SR44)	
309	309	SR754SW	V309	309			70T				SR754SW (SR48)	
315	315	SR716SW	V315	315			614	HA	280-56	SB-AT	SR716SW (SR67)	
317	317	SR516SW	V317	317	D317		616	CA	280-58	SB-AR	SR516SW (SR62)	
319	319	SR527SW	V319	319			615		280-60	SB-AE/DE	SR527SW (SR64)	
321	321	SR616SW	V321	321	D321		611	DA	280-73	SB-AF/DF	SR616SW (SR65)	
329	329	SR731SW	V329	329	D329	329					SR731SW	
335	335	SR512SW	V335	335			622		280-68	SB-AB	SR512SW	
337	337	SR416SW		337							SR416SW	
339	339	SR614SW	V339								SR614SW	
341	341	SR714SW	V341	341			627				SR714SW	
344	344	SR1136SW	V344	344			242				SR1136SW (SR42)	
346	346	SR712SW	V346	346			628		280-66	SB-DH	SR712SW	
350	350		V350		D350		604				SR1136W (SR42)	
357	357	SR44W	V357	357	D357H	357	228	J	280-62	SB-B9	SR1154W (SR44)	AG13
361	361	SR721W	V361	361				X	280-53	SB-BK/EK	SR721W (SR58)	
362	362	SR721SW	V362	362	D362	362	601	S	280-29	SB-AK/DK	SR721SW (SR58)	
364	364	SR621SW	V364	364	D364	364	602	T	280-34	SB-AG/DG	SR621SW (SR60)	
365	365	SR1116W									SR1116W	
366	366	SR1116SW	V366	366			608		280-46		SR1116SW	
370	370	SR920W	V370	370		370	620	Z	280-51	SB-BN	SR920W (SR69)	AG6
371	371	SR920SW	V371	371	D371	371	605		280-31	SB-AN	SR920SW (SR69)	AG6
373	373	SR916SW	V373	373			617	WA	280-45	SB-AJ/DJ	SR916SW (SR68)	
376	376	SR626W		376			619	MA			SR626W (SR66)	
377	377	SR626SW	V377	377	D377	377	606	BA	280-39	SB-AW	SR626SW (SR66)	AG4
379	379	SR521SW	V379	379	D379		618	JA	280-59	SB-AC/DC	SR521SW (SR63)	
380		SR936W									SR936W	
381	381	SR1120SW	V381	381			317		280-27	SB-AS/DS	SR1120SW (SR55)	AG8
384	384	SR41SW	V384	384	D384		247		280-18	SB-A1/D1	SR736SW (SR41)	
386	386	SR43W	V386	386	D386	386	260	H	280-41	SB-B8	SR1142W (SR43)	AG12
389	389	SR1130W	V389	389	D389	389	626	M	280-15	SB-BU	SR1130W (SR54)	
390	390	SR1130SW	V390	390	D390	390	603		280-24	SB-AU	SR1130SW (SR54)	AG10
391	391	SR1120W	V391	391	D391	391	609	L	280-30	SB-BS/ES	SR1120W (SR55)	AG8
392	392	SR41W	V392	392	D392	392	247B	K	280-13	SB-B1	SR736W (SR41)	AG3
393	393	SR754W	V393	393	D393		255	F		SB-B3	SR754W (SR48)	AG5
394	394	SR936SW	V394	394	D394	394	625		280-17	SB-A4	SR936SW	
395	395	SR927SW	V395	395	D395	395	610	LA	280-48	SB-AP/DP	SR927SW (SR57)	
396	396	SR726W	V396	396	D396	396	612	V	280-52	SB-BL	SR726W (SR59)	
397	397	SR726SW	V397	397	D397		607	N	280-28	SB-AL	SR726SW (SR59)	
399	399	SR927W	V399	399	D399	399	613	W	280-44	SB-BP/EP	SR927W (SR57)	
LR43	186	LR43	V12GA	RW84	LR43	186					LR1142 (LR43)	
LR44	A76	LR44	V13GA	RW82	LR44	A76		KA	280-904	SB-F9	LR1154 (LR44)	